



XQ-673H Water Tubes Replacement

This guide will show the owner how to take apart the device and show the owner how to replace the water tubes.

Written By: Sean Perry



INTRODUCTION

This guide will help the owner of a Kitchen Gourmet XQ-673H replace the water tubes.

TOOLS:

- [Small Needle Nose Pliers](#) (1)
 - [Phillips #1 Screwdriver](#) (1)
-


Step 1 — Water Tubes



⚠ Make sure the device is unplugged before continuing.



- Turn the Kitchen Gourmet upside down.

Step 2



- Using a Phillips #1 screwdriver, remove the six 10mm screws found on the bottom of the device.
- Remove the bottom cover.




Step 3



- Using a Phillips #1 screwdriver, remove the six 12mm screws.



i Some screws are not visible from this photo, but their location is highlighted by the circles.

Step 4




- Using small needle nose pliers, squeeze the metal that is covering the tube.
- Carefully slide down the metal covering.
- Repeat this step for the other tube.

Step 5




- Using your fingers, gently slide off the Water Tubes.

Step 6



- Carefully lift the bottom section off the device.

Step 7



- Using small needle nose pliers, squeeze the metal that is covering the tube.
- Carefully slide down the metal covering.
- Repeat this step for the other tube.
- Remove both of the Water Tubes completely.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-17 01:33:17 AM.